



DOYLE OFFSHORE SAILS LTD.

Six Crossroads, St. Philip, Barbados, West Indies Tel: (246) 423-4600 Fax: (246) 423-4499
Email: doyle@caribnet.net Website: www.http://doylecaribbean.com

INSTRUCTIONS FOR USE OF BATTEN POCKETS

Slide batten into pocket. Grasp pocket 8-10" from leech end of sail gently folding sail around back of pocket. With palm of 2nd hand, push batten down into pocket past the fold (about 1" from leech). Now hold batten down firmly and with thumb of 2nd hand, fold leech until it catches under fold (see diagram). When batten is in correctly, leech end of batten will not be visible.

To remove, grasp pocket 8-10" from leech and with palm of 2nd hand, push down on leech end of batten. Release pressure letting batten slide out against sail side of pocket.

Inner fold (approx. 1")

BATTEN

Leech of Sail

